

# Ronseal Promise, if you do exactly what it says on the tin, this product will do exactly what it says on the tin.

# **DECKING CLEANER & REVIVER**Cleans & revives decking in minutes

Ronseal Decking Cleaner & Reviver is specially formulated to clean and revive weathered or tired timber decking. The fast acting formula removes moss, mould and algae whilst also brightening the wood and restoring it back to its natural appearance. Ronseal Decking Cleaner & Reviver is ideal for use prior to treatment, opening the pores of the wood allowing maximum adhesion of the coating and a longer lasting finish.

#### Where can it be used?

Ronseal Decking Cleaner & Reviver can be used to clean any type of decking timber, bare or coated, as part of a maintenance programme. It can also be used on fences, wooden garden furniture and exterior wood. NB: Ronseal Decking Cleaner & Reviver will not remove the green tint found on some preservative impregnated timber.

### Directions for use

Always test an inconspicuous area before starting general application to ensure the desired result is achieved.

- 1. Remove debris and accumulations of moss, mould and algae using a stiff brush.
- Pour Ronseal Decking Cleaner & Reviver directly on to your deck.
- **3.** Scrub the surface immediately using a stiff brush then leave for 15-20 minutes.
- 4. For best results wash off thoroughly with a pressure washer. Work from one end of a decking board to the other in a continuous motion. Alternatively scrub the surface using a stiff brush and then hose down. All cleaning residues must be completely washed away in order to maximise the performance of subsequent coatings.

#### Precautions

Surface may become slippery during cleaning. If Ronseal Decking Cleaner & Reviver comes into contact with surrounding grass or plants rinse thoroughly with water. Please note: Ronseal Decking Cleaner & Reviver may remove partially deteriorated or flaking coatings.

# **Drying Time**

Surfaces which have been cleaned should be completely dry prior to application of protective coatings (allow at least two days).

## Coverage

This 5 litre pack is sufficient to clean a deck equivalent to 20-24 square metres in area.

## Clean Up

All equipment should be cleaned using plenty of water and detergent. Some local authorities have special facilities for disposing of waste products. Do not empty undiluted product into drains or watercourses.

### **Maintenance and Protection**

Decking should be inspected on an annual basis, cleaning and/or recoating as appropriate. After using Ronseal Decking Cleaner & Reviver use Ronseal decking oil, stain or seal to maintain and protect your deck.

## Ronseal Decking Cleaner & Reviver

Avoid contact with skin and eyes. In case of contact with eyes rinse immediately with plenty of water and seek medical advice. Do not breathe spray. In case of insufficient ventilation wear suitable respiratory equipment. Keep out of the reach of children. Protect from frost. Ensure container is fully resealed after use.

# THIS PRODUCT CONTAINS AMONGST OTHER INGREDIENTS

Less than 5%	Non-Ionic surfactants
Less than 5%	Phosphate
Preservatives	

#### For further advice please contact: Ronseal Technical Services, Tel: 0114 240 9469

Ronseal Ltd. Thorncliffe Park, Chapeltown, Sheffield S35 2YP Tel: 0114 246 7171 Fax: 0114 245 5629 enquiry@ronseal.co.uk www.ronseal.co.uk



5 Litres ⊖



Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of The Sherwin-Williams Company. © 2010



L0376