

DOES
EXACTLY
WHAT IT
SAYS ON
THE TIN™

**Ronseal Promise, if you do exactly what it says on the tin,
this product will do exactly what it says on the tin.**

What Is Ronseal Garden Furniture Reviver?

Ronseal Garden Furniture Reviver has been developed to bring old or greyed hardwood furniture back to a natural colour with the minimum of effort and fuss.

Where should it be used?

Ronseal Garden Furniture Reviver can be used to bring any weathered hardwood garden furniture back to life. It is also ideal for use on smooth planed garden wood such as gates etc.

Coverage

Ronseal Garden Furniture Reviver can treat up to 9m² per litre per application.

Preparation

Remove any previous coatings from the affected/weathered wood using sandpaper or a wire brush. Avoid the inhalation of dust, wear a suitable face mask when sanding. Remove any dirt, moss, fungal growth and lichens with a stiff brush. The treatment of a test area to determine final colour suitability is recommended. Protect adjacent metallic or painted surfaces from splashes.



Application

- 1 Stir well before and during use.
- 2 Avoid using the product in direct sunlight as this will cause it to dry out too quickly.
- 3 Brush out liberally covering the area affected. Re-apply if drying out occurs.
- 4 Leave at least three hours, then scrub off all traces of furniture reviver with water and a scrubbing brush. The process may be repeated if required.

When using the product, wear protective clothing as Ronseal Garden Furniture Reviver may damage some fabrics. Allow to dry thoroughly. Lightly sand the surface to a smooth finish if required and finish with an appropriate Ronseal product.

Ronseal recommends you protect newly revived wood with either Ronseal Hardwood Furniture Stain or Furniture Oil.

For further advice please contact:
Ronseal Technical Services,
Tel: 0114 240 9469

Ronseal Ltd, Thorncliffe Park,
Chapeltown, Sheffield S35 2YP
Tel: 0114 246 7171 Fax: 0114 245 5629
enquiry@ronseal.co.uk


www.ronseal.co.uk

Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of the Sherwin-Williams Company © 2010. Made in UK

RONSEAL GARDEN FURNITURE REVIVER

Contains: Phosphoric acid 24.5%

Irritating to eyes and skin.
Keep out of reach of children.
Avoid contact with skin and eyes.
In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
After contact with skin, wash immediately with plenty of water.
Wear suitable gloves and eye/face protection.
If swallowed seek medical advice immediately and show this container label. If swallowed, rinse mouth with water (only if the person is conscious). To avoid the risk of spillage, always store and transport in a secure and upright position.



23722

1 litre e