

# RONSEAL

## HIGH PERFORMANCE

# DECKING CLEANER

Ronseal High Performance Decking Cleaner is a fast and effective way to clean and restore decking. Simply dissolve the easy-to-use capsules into water and apply. The high performance formula kills moss, mould and algae and restores the natural beauty of the deck whilst inhibiting the regrowth of moss and mould. It is ideal for use prior to treatment, opening the pores of the wood allowing maximum adhesion of the coating and a longer lasting finish. Contains no bleach or acids. For the ultimate ease of application Ronseal Decking Cleaner can be used with a Ronseal sprayer.

### Areas of use

Ronseal High Performance Decking Cleaner is suitable for use on any type of decking timber, bare or coated.

### Preparation

Remove any debris including leaves, twigs, loose soils, weeds and large accumulations of moss and mould from the decking with a stiff brush. Do not wet the surface.

### Application

Ronseal High Performance Decking Cleaner requires dilution with water. Remove the capsules from the outer packaging and cut the inner case with scissors to remove the capsules. Note: If using scissors or a sharp object to

cut the inner case be careful not to pierce the capsules. Place one capsule into 2.5 litres of warm water or two capsules into 5 litres of warm water. Warm water will speed up the dissolution of the capsules. Stir and leave the capsules to dissolve for 90 seconds. If using cold water this will take up to 3 minutes. Apply the cleaner with a watering can, Ronseal sprayer or brush to the surface to be treated. Scrub the surface well with a stiff bristle brush and leave for 10-15 minutes. Re-scrub the surface and then wash off with a brush and water, or hose down ensuring all residues are washed away.

### To use as a mould and algae cleaner

To remove the green appearance of mould and algae without the need to scrub. Once diluted, simply apply to the area to be treated and leave for 2-3 days. Any green appearance will simply disappear. If required brush the surface after a week or so to remove any debris.

### Coverage

Once diluted, 5 litres of Ronseal High Performance Decking Cleaner will treat approximately 20-24 sqm.

### Precautions

Please note Ronseal Decking Cleaner may remove partially deteriorated or flaking coatings.

### HEALTH & SAFETY

Contains: Alkyldimethylbenzyl ammonium chloride (C12-C14)  
Harmful if swallowed. Risk of serious damage to eyes. Very toxic to aquatic organisms. Keep out of reach of children. Keep away from food, drink and animal feedstuffs. Do not breathe vapour/spray. Avoid contact with skin and eyes. In case of contact with eyes rinse immediately with plenty of water and seek medical advice.

Do not empty into drains, dispose of this material and its container to a hazardous or special waste collection point. After contact with skin, wash immediately with plenty of water. In case of insufficient ventilation, wear suitable respiratory equipment. Wear eye/face protection. In case of accident or if you feel unwell, seek medical advice immediately (show label where possible). If swallowed seek medical advice immediately and show this container or label.



HARMFUL



DANGEROUS FOR THE ENVIRONMENT

This product is a 125 times concentrate of HSE 9022. This product contains amongst other ingredients more than 10% non ionic surfactant.

### For further advice please contact:

**Ronseal Technical Services, Tel: 0114 240 9469**

Ronseal Ltd. Thorncliffe Park, Chapelton, Sheffield S35 2YP Tel: 0114 246 7171 Fax: 0114 245 5629 enquiry@ronseal.co.uk

[www.ronseal.co.uk](http://www.ronseal.co.uk)

## 2 x 20ml capsules e



**Made in Great Britain**

Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of The Sherwin-Williams Company. © 2010

L03647

## HIGH PERFORMANCE

# DECKING CLEANER

QUICKEST AND EASIEST WAY TO CLEAN GARDEN DECKING