

**DOES
EXACTLY
WHAT IT
SAYS ON
THE TIN™**

**Ronseal Promise, if you do exactly what it says on the tin,
this product will do exactly what it says on the tin.**

Ronseal High Performance Wood Filler is a resin based interior and exterior wood filler that fills to any depth and dries in 30 minutes. It is suitable for use on major repairs and to fill damage caused by wet rot, especially when used in conjunction with **Ronseal Wet Rot Wood Hardener**.

- Can be stained, varnished and painted
- Easy to sand
- Will survive the most extreme conditions
- Flexible formula for use both indoors and outdoors
- Can be drilled, sanded, planed, carved, screwed and filed
- Resists shrinking and cracking

USAGE AREAS

Ideal for use in interior or exterior wood repairs more than 5 mm deep. Typical areas include window frames, sills, doors and door frames. For minor and surface wood repairs use **Ronseal Multi Purpose Wood Filler**.

PREPARATION

Ensure area is clean, dry and free from loose wood, paint or varnish. Softened wood, like that caused by wet rot, should be removed as much as possible and treated with **Ronseal Wet Rot Wood Hardener** which strengthens and reinforces rotten fibres to provide a solid base for the filler. For holes deeper than 2.5 cm insert non-rusting screws into the wood leaving the heads proud to provide anchorage for the filler.

APPLICATION

1. Measure out a 38mm line of catalyst using the measure on the spreader included in the pack.
2. Using a folding action, mix a golf ball volume of filler, approximately 38mm diameter, with the catalyst. The plastic lid is a good base for mixing.
3. Mix until filler and catalyst are thoroughly combined and uniform in colour.
4. Apply the filler working well into the repair. Working time is approximately 10 minutes.
5. Leave the filler slightly proud for sanding.
6. After 20 minutes the filler can be carved or shaped with a modeling knife. After 30 minutes the filler can be sanded, planed or filed.
7. Finish with a stain, varnish or paint.

NOTE: Not suitable for gaps between floorboards. Due to the nature and different absorbency levels of wood the filler may stain/varnish differently to the surrounding wood. Working time is reduced in hot temperatures and with high amounts of catalyst and extended in cold temperatures.

CLEAN UP

Wipe tools clean before filler is dry or use cellulose thinners.

WISE PRECAUTIONS

Do not return mixed filler back into the pack. Store in a cool place. Protect from freezing. Only for use as directed.



Harmful

Ronseal Wood Filler contains Styrene. Flammable. Harmful; by inhalation. Irritating to eyes and skin. Do not breathe fumes. Avoid contact with skin and eyes. In case of contact with eyes rinse immediately with plenty of water and seek medical advice. If swallowed, seek medical advice immediately and show this container or label. Keep out of the reach of children. Do not return mixed filler back into the pack. Store in a cool place. Protect from freezing. Only for use as directed.



**For further advice please contact:
Ronseal Technical Services,
Tel: 0114 240 9469**

Ronseal Ltd. Thorncliffe Park,
Chapelton, Sheffield. S35 2YP
Tel: 0114 246 7171 Fax: 0114 245 5629
enquiry@ronseal.co.uk

www.ronseal.co.uk

RONSEAL AND RONSEAL DOES
EXACTLY WHAT IT SAYS ON
THE TIN ARE REGISTERED
TRADEMARKS OF THE
SHERWIN-WILLIAMS COMPANY
© 2010. MADE IN UK



550g e

