

**DOES  
EXACTLY  
WHAT IT  
SAYS ON  
THE TIN™**

**Ronseal Promise, if you do exactly what it says on the tin,  
this product will do exactly what it says on the tin.**

## What is Ronseal Hardwood Furniture Stain?

Ronseal Hardwood Furniture Stain is designed to provide long lasting colour and protection for hardwood garden furniture. The lightly pigmented formulation adds natural colour to wood without obliterating the natural wood grain, protecting against fading and delivering a guaranteed 3 years of colour. The all-weather formulation protects garden furniture against the elements, delivering increased water and UV resistance, helping to prevent hardwoods from cracking, splitting or discolouring. With a rapid 1 hour drying time, garden furniture is back in use faster than with traditional hardwood stains.

### Where should it be used?

Ronseal Hardwood Furniture Stain has been developed to deliver superior colour and protection to any exterior hardwood furniture. It is also suitable for use on softwood furniture.

### How many coats?

3 coats are required to achieve 3 year colour protection.

### Coverage

750ml will cover 4m<sup>2</sup> with 3 coats.

### Drying Times

Touch dry in 1 hour, allowing 4 hours between coats. Some oily hardwoods such as teak and iroko may lengthen drying times

### Preparation

Make sure the wood is clean and dry. Lightly sand to remove any loose wood fibres and wipe off any dirt, dust and grease. Always wipe down the surface with white spirit before application to remove any natural oils and resins. Weathered wood and painted or varnished wood should be sanded back to clean sound wood, then treated as bare wood. Avoid the inhalation of dust and wear a suitable face mask when sanding. Previously oiled hardwoods should be sanded and then cleaned down with white spirit. Always test for colour on a small inconspicuous area before use.

### Application

1. Stir well before and during use.
2. Apply even coats brushing in the direction of the grain avoiding overlaps.

3. Apply 3 coats, allowing 4 hours between coats.  
Pay particular attention to sealing joints and all end grains.
4. Do not apply in wet conditions or if rain is likely before the product is dry. Final colour and coverage will vary depending on the type and absorbency of the wood.
5. Allow coating to dry thoroughly before placing soft furnishings in contact with the hardwood (leave 48 hours).

### Clean Up

Wash brushes out with detergent and warm water. Clean up any spills whilst still wet. Remove as much product from the brush as possible before cleaning. Some local authorities have special facilities for disposing of waste products. Do not empty into drains or water courses.

### WISE PRECAUTIONS

Keep out of the reach of children. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, wash immediately with plenty of water. Use only in well ventilated areas. To avoid the risk of spillage, always store and transport in a secure and upright position.

### For further advice please contact:

#### Ronseal Technical Services,

Tel: 0114 240 9469

Ronseal Ltd., Chapeltown,  
Sheffield S35 2YP

Tel: 0114 246 7171,

Fax: 0114 245 5629

E-mail: enquiry@ronseal.co.uk

[www.ronseal.co.uk](http://www.ronseal.co.uk)

Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of The Sherwin-Williams Company. © 2010



C00215

**750ml e**

