

**DOES
EXACTLY
WHAT IT
SAYS ON
THE TIN™**

Ronseal Promise, if you do exactly what it says on the tin, this product will do exactly what it says on the tin.

What is Ronseal Hardwood Garden Furniture Oil?

Ronseal Hardwood Garden Furniture Oil penetrates the wood to revive colour and replace oils lost through weathering. Its superior combination of oils and resins delivers improved water repellency and flexes with the natural movement of the wood for long lasting protection against the elements. It nourishes the wood from the inside out and its rapid dry time of 2 hours means your garden furniture is back in use much faster than with teak oils and other garden furniture oils.

Where can I use it?

Ronseal Hardwood Garden Furniture Oil has been specifically developed for use on all quality hardwoods including Teak, Oak, Mahogany and Iroko. Its durable formulation means it is ideal for use on high wear areas such as tables and chairs.

Preparation

Remove all previous coatings such as paint, varnish and woodstain. Lightly sand to remove any loose wood fibres. Avoid the inhalation of dust, wear a suitable face mask when sanding. Remove dust, dirt and grease by wiping over with white spirit. Always test for finish on a small inconspicuous area.

Application

1. Ensure surface is dry and clean.
2. Apply liberally using a soft, dry, lint free cloth.
3. Work lightly into grain. Wipe off any excess.
4. Re-apply as necessary once the previous coat has dried.
5. Three coats will provide adequate protection. Leave 6 hours between coats.

Maintain regularly with a further coat of Ronseal Hardwood Garden Furniture Oil to ensure lasting protection.

Drying Times

In good weather conditions Ronseal Hardwood Garden Furniture Oil is touch dry in 2 hours.

Clean Up

Some local authorities have special facilities for disposing of waste products. Do not empty into drains or water courses. Ensure container is fully re-sealed after use. Warning: cloths and soiled rags may self ignite without warning. Wash out well in warm soapy water before disposal.

RONSEAL HARDWOOD GARDEN FURNITURE OIL

Flammable. Harmful to aquatic organisms, may cause long-term adverse effects in the aquatic environment. Repeated exposure may cause skin dryness or cracking. Keep out of the reach of children. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Wear suitable gloves. If swallowed, seek medical advice immediately and show this container or label. Use only in well ventilated areas. Dispose of this material and its container to hazardous or special water collection point. Contains Cobalt 2-Ethylhexanoate, ETHYL METHYL KETOXIME. May produce an allergic reaction. Application cloths and soiled cleaning rags may self-ignite without warning. Dispose of safely to avoid contact fire risks. After contact with skin, wash immediately with plenty of water.

C00225

**For further advice please contact:
Ronseal Technical Services,**

Tel: 0114 240 9469

Ronseal Ltd.,

Chapeltown,

Sheffield S35 2YP

Tel: 0114 246 7171,

Fax: 0114 245 5629

E-mail: enquiry@ronseal.co.uk

www.ronseal.co.uk

Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of The Sherwin-Williams Company. © 2010



1 litre e

