

DOES
EXACTLY
WHAT IT
SAYS ON
THE TIN™

Ronseal Promise, if you do exactly what it says on the tin,
this product will do exactly what it says on the tin.



NOURISHMENT

Nourishes and restores
the woods natural oils



COATS

3 coats will provide adequate
protection to weathered wood



LOW ODOUR



DRY TIMES

- Touch dry in 1 hour
- Recoat in 4 hours



CLEANING

Pad washes out in water

Ronseal Perfect Finish Garden Furniture Oil is the quickest and easiest way to nourish, enhance and protect hardwood garden furniture and is a superior alternative to Teak Oil. The penetrating formula feeds the wood, replacing the natural oils lost through the weathering process. It includes the unique Perfect Finish Garden Furniture pad which helps you achieve a perfect finish to your valued wood first time and everytime. The specially engineered corrugated flock ensures even application of the oil and the flexible edge means the pad can reach between the slats to deliver all over nourishing protection more effectively and with less mess than using a cloth.

Preparation: Ronseal Perfect Finish Garden Furniture Oil should only be used over bare hardwood or as a maintenance coat over previously oiled furniture. It is not suitable for use on softwood. Remove all previous coatings such as paint, varnish and woodstain and lightly sand to remove any loose and grey wood fibres. Remove dust, dirt and grease by wiping over with white spirit. Always test for finish in an inconspicuous area. Previously oiled furniture should be wiped down thoroughly with white spirit.

Application: Stir thoroughly before and during use. After assembling the Perfect Finish pad (instructions included in pack), lower the green corrugated flock into the Furniture Oil ensuring the tips of the raised corrugations are covered. Apply consistent pressure as you push/pull the pad in the direction of the grain with the corrugations at 90 degrees to the woodgrain to achieve a smooth finish. Use the flexible edge to reach between slats for all over coverage. For best possible results, lightly sand before the final coat.

Clean Up: Remove as much product as possible before washing the pad out in detergent and water. Allow pad to dry with flock facing upwards.

RONSEAL PERFECT FINISH GARDEN FURNITURE OIL

Keep out of reach of children. Avoid contact with skin and eyes. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. After contact with skin, wash immediately with plenty of water. Use only in well-ventilated areas. Protect from frost. Do not apply in temperatures below 10°C or in conditions of high humidity.



For further advice please contact:

Ronseal Technical Services
Tel: 0114 240 9469
Ronseal Ltd, Chapelton,
Sheffield, S35 2YP.
Tel: 0114 246 7171
Fax: 0114 245 5629
enquiry@ronseal.co.uk
www.ronseal.co.uk

Made in Great Britain.

Ronseal & Ronseal Does Exactly What It Says On The Tin are registered trademarks of the Sherwin-Williams Company. Ronseal Perfect Finish is a trademark of the Sherwin-Williams Company.
© Ronseal 2010 Patent Pending

750ml e

